



Note:

An extended ramp flange is used when integrating in the ramp incline.

Technical data:

- INTEGRA-pw Fastening flange
- INTEGRA-pw Crest
- INTEGRA-pw Counter flange

Tightening torque bolts:

- M10 = 30 Nm
- M16 = 100 Nm



German Approval

Installation instructions:
 The crest must always be installed starting in the first INTEGRA-pw grid field, so that a max. slipping distance is attained.
 The beads can be oriented towards the parking deck or away from it.

