



**Installation instructions:**  
 The crest must always be installed starting in the first INTEGRA-pw grid field, so that a max. slipping distance is attained.

The beads can be oriented towards the parking deck or away from it.

**Note:**  
 An extended ramp flange is used when integrating in the ramp incline.

**Technical data:**  
 INTEGRA-pw Fastening flange  
 INTEGRA-pw Crest  
 INTEGRA-pw Counter flange

All bolts must be tightened with a torque of 50 Nm.



Fastening see Data sheet 111

